EB5000X3C



- $_{\rm l}$ $\,$ Dual voltage power with premium features and $\,$ GFCI protection
- 1 5000 watts maximum AC output
- 1 Industrial applications and Commercial usage
- 1 Suitable for rental applications



SPECIFICATIONS			
MAXIMUM AC OUTPUT (WATTS)	5000	BATTERY	N/A
AC Voltage Available	120/240	Approximate Running Time/Tankful (hrs)	8.1**/11.2****
MAXIMUM CONTINUOUS AC OUTPUT (WATTS)	4,500 7,000 (iAVR)	Rated Fuel Consumption (Litres/Hour)	2.90**
Max. Rated AC Amperage @ 120 V/240 V	37.5/18.8 (58.3/29.2 for 10 sec. iAVR)	Noise Level dB(A) (1.5 m to 7 m)	72**
GROUND FAULT CIRCUIT INTERRUPTER (GFCI)	Standard	Length (Without Handles and Wheels)	681 mm (26.8 in.)
FREQUENCY (HERTZ)	60	Length (With Handles and Wheels)	1,043 mm (41.1 in.)
AUTOMATIC VOLTAGE REGULATOR	Standard iAVR (Intelligent Automatic Voltage Regulator)		
DC Output Volts/Amps	N/A	Width (Without Handles and Wheels)	530 mm (20.9 in.)
Engine Type	Honda iGX390T2 OHV, 4-stroke, air-cooled	Width (With Handles and Wheels)	706 mm (27.8 in.)
DISPLACEMENT	389 cc	Height (Without Lift-Hook)	719 mm (28.3 in.)
STARTING SYSTEM	Manual recoil	Height (With Lift-Hook)	773 mm (30.4 in.) standard
Low Level Oil Alert System	Standard	DRY WEIGHT	94.6 kg (208.6 lb.)
AUTO THROTTLE	Standard	COLD CLIMATE TECHNOLOGY	Standard
REMOTE START CAPABILITY	No		
FUEL TANK CAPACITY (LITRES)	23.5	Common Duplex Receptacle Specifications	37.5 amps/120 VAC continuous is available as combined total from these twin duplex AC receptacles. Maximum of 18.8 amps available from each GFCI duplex receptacle.
TRANSPORT WHEELS	2 Wheel standard		
LIFTING HOOK	Standard	DC Charging Cable	-
		High Capacity 120/240 VAC Twist Lock Receptacle Specs	This receptacle will supply 30 amps at 120 VAC continuously. This receptacle will supply 18.8 amps (4.5 kVA) at 240 VAC continuously
		Distributor's Warranty (commercial use)	36-month
		Distributor's Warranty (non-commercial use)	36-month

Models and/or colours may not be exactly as shown. Errors and omissions excepted. Specifications are subject to change without notice. See your Honda Power Equipment dealer for details.

For optimum performance and safety, please read your owner's manual before operating your Honda product. Always wear the appropriate safety gear when operating your Honda.

 $@/\mathsf{TM} - \mathsf{Trademarks} \ \mathsf{of} \ \mathsf{Honda} \ \mathsf{Canada} \ \mathsf{Inc.} \ \mathsf{or} \ \mathsf{used} \ \mathsf{under} \ \mathsf{licence} \ \mathsf{from} \ \mathsf{Honda} \ \mathsf{Motor} \ \mathsf{Co.}, \ \mathsf{Ltd.} \ \mathsf{or} \ \mathsf{third} \ \mathsf{parties}.$